


Sony PCS-1 Installation

NOTE: Requires special adapter cable - XLR Female to 3.5 mm mini connector.



Step 1

Step 2

1. Plug the red RCA connector on one end of **Cable C** into Sony video-station <Audio Out> (not MIXED), and then plug the red RCA connector on the other end into the Fusion Base Station <Conf In>.
2. Plug one XLR connector of **Cable D**, XLR to XLR, into XLR Female to 3.5mm adapter cable and then to the Sony video-station <Mic 1 Input> and the other XLR connector into the Fusion Base Station Mic Level Output <XLR>.

To configure the Sony PCS-1:


Select the **Audio** settings drop down menu.
Confirm or modify the following settings:

- **Input Select - MIC**
- **MIC Select - MIC**
- **Echo Canceller - OFF**
- **CTE - OFF**

Press **SAVE** to save changes.

Sony PCS-G50 or G70 Installation

NOTE: Requires special adapter cable - XLR Female to 3.5 mm mini connector.



Step 1

Step 2

3. Plug the red RCA connector on one end of **Cable C** into Sony video-station <Audio Out 1>, and then plug the red RCA connector on the other end into the Fusion Base Station <Conf In>.
4. Plug one XLR connector of **Cable D**, XLR to XLR, into XLR Female to 3.5mm adapter cable and then to the Sony video-station <Mic 1 Input> and the other XLR connector into the Fusion Base Station Mic Level Output <XLR>.

To configure the Sony PCS-G50 or G70 system:

:
Select the **Audio** settings drop down menu.
Confirm or modify the following settings:

- **Input Select - MIC**
- **MIC Select – MIC**
- **Echo Canceller - OFF**
- **CTE – OFF**

Press **SAVE** to save changes.

Sony PCS-HG90 Installation



Step 1

Step 2

5. Plug one XLR connector of **Cable D**, XLR to XLR into the Sony video-station <Mic 1 Input> and the other XLR connector into the Fusion Base Station Mic Level Output <XLR>.
6. Plug the red RCA connector on one end of **Cable C** into Sony video-station <Audio Out 1>, and then plug the red RCA connector on the other end into the Fusion Base Station <Conf In>.

To configure the Sony PCS-HG90 system:

:
Select the **Audio** settings drop down menu.
Confirm or modify the following settings:

- **Input Select - MIC**
- **Audio In – MIC**
- **Input Mode – MONO**
- **Output Mode - MONO**
- **Echo Canceller - OFF**

Press **SAVE** to save changes.